ESSENTIAL ALUMINUM PRE-ASSEMBLED RAIL INSTALLATION INSTRUCTIONS

WHAT IS INCLUDED

A. Rail Panel (1)
B. Top Bracket (2)
C. Bottom Bracket (2)
D. Support Block (1 for 6ft, 2 for 8ft)
E. Support Block Connector(s)
F. Hardware Pack

NOT INCLUDED

- 2-1/2” x 2-1/2” Aluminum Post Kit

TOOLS AND ITEMS NEEDED


- Power Drill
- 5/32" Drill Bit
- T20 Torx Bit (provided)
- Miter Saw
- Pencil
- Speed Square
- Tape Measure
- Two small pieces of 2x4 wood (optional)


IMPORTANT NOTES

- The 6ft kit is designed for a span of 69-1/2" between posts and the 8ft spans 93-1/2" between posts.
- Gap between deck surface and bottom rail = 3-1/2"
- Height of top rail = 36" (or 42" for the 42" Rail Kit)

BEFORE YOU BEGIN


- Check with your local regulatory agency for special code requirements in your area. Common railing height requirement is 36" or 42”
- Read instructions completely before assembly to get an understanding of how the product goes together and how each piece affects the other.
- Determine the number of railing posts needed and post spacing for your deck. Post spacing maximum will be 69-1/2" between the posts (not including bases) for 6' railing and 93-1/2" between the posts (not including bases) for 8' railing. Refer to the post installation instructions to install the proper under deck joists and blocking materials to align with the holes in the post bases prior to installing your decking materials.






STEP 1 – Shorten Panel Length (If Needed)

- The 6ft kit is designed for a span of 69.5”. The 8ft kit is designed for a span of 93.5”. Proceed to Step 2 if you don’t need to shorten.
- Measure the desired span between the posts.
- Subtract ¼” from that dimension for your panel length and mark the rails. The marks should be equally spaced between balusters.
- If the balusters are within 1-1/2” of either mark (after the proposed cut), you must shift the cut marks to either side so the balusters do not interfere with the brackets.
- Properly secure the rail panel and cut on the cut marks.




STEP 2 – Install Support Block Connectors

- Any section of railing greater than 3ft will require (1) centered support block; any section of railing greater than 6ft will require (2) equally spaced support blocks.
- Position the support block connector(s) under the bottom rail. Pre-drill using a 1/8" drill bit and attach using the supplied #8 x 1" Flathead screw.
- Temporarily set the rail in place, centered between the posts. Mark the deck surface where the support block connector(s) touches.
- Remove the rail and attach the other crush block connector(s) to the deck surface, directly below the other connector(s). Pre-drill using a 1/8" drill bit and use the supplied #8 x 1" Flathead screw.




STEP 3 – Slide Brackets Onto Rail Ends

- Slide both top brackets over the top rail ends as shown.
- Do the same for both bottom brackets.




STEP 4 – Set Railing Into Position

- **PRO TIP:** Cut two pieces of a 2x4 to put under the rail during installation. The gap is 3.5" from the deck to the bottom rail.
- Attach the support block to the connector on the bottom of the rail panel and set the assembly onto the previously attached support block connector on the deck surface.




STEP 5 – Attach Top Brackets to Posts

- Slide the bracket towards the post until it is flush and centered on the post.
- Drill a 5/32" pilot hole in the post using the holes in the bracket as a guide.
- Attach the brackets to the post using (2) provided #10 x 1/2" screws.
- Repeat for the other top bracket.




STEP 6 - Attach Bottom Brackets to Posts

- Slide the bracket towards the post until it is flush and centered on the post.
- Drill a 5/32" pilot hole in the post using the holes in the bracket as a guide.
- Attach the brackets to the post using (2) provided #10 x 1/2" screws.
- Repeat for the other top bracket.



STEP 7 – Attach Top Brackets to Rail

- Drill a 5/32" pilot hole in the rail using the holes in the bracket as a guide.
- Attach the brackets to the rail using (2) provided #10 x 1/2" screws.
- Repeat for the other top bracket.



STEP 8 – Attach Bottom Brackets to Rail

- Drill a 5/32" pilot hole in the rail using the top hole in the bracket as a guide.
- Attach the brackets to the rail using (1) provided #10 x 1/2" screw.
- Repeat for the other bottom bracket.

THE DIAGRAMS AND INSTRUCTIONS IN THIS BROCHURE ARE FOR ILLUSTRATION PURPOSES ONLY AND ARE NOT MEANT TO REPLACE A LICENSED PROFESSIONAL. ANY CONSTRUCTION OR USE OF THE PRODUCT MUST BE IN ACCORDANCE WITH ALL LOCAL ZONING AND/OR BUILDING CODES. THE CONSUMER ASSUMES ALL RISKS AND LIABILITY ASSOCIATED WITH THE CONSTRUCTION OR USE OF THIS PRODUCT. THE CONSUMER OR CONTRACTOR SHOULD TAKE ALL NECESSARY STEPS TO ENSURE THE SAFETY OF EVERYONE INVOLVED IN THE PROJECT, INCLUDING, BUT NOT LIMITED TO, WEARING THE APPROPRIATE SAFETY EQUIPMENT. EXCEPT AS CONTAINED IN THE WRITTEN LIMITED WARRANTY, THE WARRANTOR DOES NOT PROVIDE ANY OTHER WARRANTY, EITHER EXPRESS OR IMPLIED, AND SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES.

©2026 UFP Retail Solutions, LLC. All rights reserved.

68956 U.S. Highway 131, White Pigeon, MI 49099